



INSTALLATION INSTRUCTIONS

Tech Support
856-768-5700 EXT 2
TechSupport@LEDGlow.com

6 Piece Flexible Million Color LED Motorcycle Lighting Kit

Warning: Please check your state and local laws before installing this kit. Each state has different policies and procedures in place for aftermarket lighting accessories. LEDGlow is not responsible for any fines that you may incur while using this motorcycle underglow kit. This kit is for off road use only.

Warning: LEDGlow recommends that this kit is installed by a licensed professional. Damage caused to this kit due to improper installation will void all warranties.

The Control Box must be installed in a dry location! If the control box is exposed to water it will cause it to fail. If any water damage and/or corrosion occur to the control box it will VOID all warranties.

Please read the following instructions thoroughly before installing your kit.

1. Arrange the tubes out on the ground the way you plan to install them on the motorcycle. Test the kit to ensure proper functionality before installing.
2. Remove any faring or trim pieces that may hinder the installation of this kit. **(Optional)**
3. First, mount the front tubes. Be sure to keep them away from any direct heat source or moving parts. Make sure the power wires are away from the fan, exhaust, and brakes. Make sure there is at least 10 inches in between the exhaust and the motorcycle lighting tube. Be sure to keep the power wires and motorcycle lighting tubes away from any suspension parts. You can use the provided mounting brackets or wire ties to hold each motorcycle lighting tube in place. If you use the provided brackets also use a wire tire to secure each motorcycle lighting tube to the bracket. **IMPORTANT: DO NOT DRILL HOLES OR ATTACH MOUNTING BRACKETS WITH SCREWS TO THE RADIATOR OR FUEL TANK.**
4. Mount the second set of motorcycle lighting tubes to the frame above the engine compartment or below the gas tank. Make sure to be aware of the brake lines and fuel lines so you do not damage them. Be sure not to mount the motorcycle lighting tubes too close to the exhaust. Make sure there is at least 10 inches in between the exhaust and the motorcycle lighting tube. Be sure to keep the power wires and motorcycle lighting tubes away from any suspension parts. You can use the provided mounting brackets or wire ties to hold each motorcycle lighting tube in place. If you use the provided brackets also use a wire tire to secure each motorcycle lighting tube to the bracket. **IMPORTANT: DO NOT DRILL HOLES OR ATTACH MOUNTING BRACKETS WITH SCREWS TO THE RADIATOR OR FUEL TANK.**
5. Mount the rear motorcycle lighting tubes last. A good location would be under tail or to the swing arms. Be sure to keep the motorcycle lighting tubes and power wires away from the rear tire, and leave at least 10 inches between the exhaust and each motorcycle lighting tube. Be sure to keep the power wires and motorcycle lighting tubes away from any suspension parts. You can use the provided mounting brackets or wire ties to hold each motorcycle lighting tube in place. If you use the provided brackets also use a wire tire to secure each motorcycle lighting tube to the bracket.
6. Find a safe, secure, and dry place to mount the control box. We recommend mounting it under the seat or in a water tight compartment if possible, as well as, running the distributor cable to a dry location. If this is not possible then we suggest putting the box in the driest place available. **The control box is not designed to withstand any water damage, and if any does occur it will void all warranties. Optional: Seal the seams of the control box with silicone to prevent water damage.**
7. Connect the red power wire to a 12 volt source. If the power wire needs to be extended be sure to sue only 14 or 16 gauge automotive grade wire. If you are running the power wire directly to the battery, and must go through the frame or any other metal parts, make sure to protect the wire by using an existing grommet or by drilling a new hole and adding a new grommet. Be sure to install a fuse within 6 inches of the power source. **(Fuse is not included if you have to extend the wires.)** Connecting the red power wire to a constant 12 volt source will allow the kit to remember the last color and pattern it was on prior powering down the motorcycle, if the red power wire is connected to a switched 12 volt power source the kit will not remember the last color and pattern it was last on. If you are running the red power wire to the fuse block, LEDGlow recommends that you install the wire using an add-a-circuit which is available online at www.LEDGlow.com.
8. Connect the black wire to a ground source located on the frame. You can connect the black ground wire directly to the battery or any engine ground.

INSTALLATION INSTRUCTIONS



Tech Support
856-768-5700 EXT 2
TechSupport@LEDGlow.com

9. Starting with the rear tubes and working your way to the front of the bike, run each power wire to the location of the control box. Make sure to secure all power wires when going around the exhaust or any suspension parts. Make sure there is at least 10 inches in between the exhaust and the motorcycle lighting tubes. If a wire is pinched it could cause the kit to malfunction, and may void the warranty due to physical damage.
10. After all of the motorcycle lighting tubes are installed, and the power wires are run to the control box check each p wire to ensure it is secure and away from any direct heat source or moving parts.
11. **DO NOT SHORTEN OR CUT THE WIRES. You will destroy the kit and void the warranty.**
12. If any parts were removed for the light kit installation you can now reinstall them and test out your new kit.
13. With the vehicle on the ground, push on the suspension as far as it can go in both directions to ensure that there will be no tubes and or wires coming in contact with the tire as you are going down the road. If a tube or wire is damaged by the tire the warranty will be voided.

4 Button Wireless Remote Operation

- Button A: Pattern and Color Change
- Button B: Power On/Off
- Button C: Speed Down Function
- Button D: Speed Up Function

For accessories, replacement parts, and / or technical support please visit www.LEDGlow.com for more information.

Limited Warranty and Disclaimer

All LEDGlow Lighting, LLC. products come with a one year limited warranty on the internal parts of the product. This warranty starts from the date of purchase. LEDGlow Lighting, LLC. will replace or repair any qualifying defective product received by the company before the end of the warranty period. Installation of this product must be performed by a licensed professional. Should the failure of the product be the result of damage occurring as a result of improper installation, alteration of the product or an act or omission on the part of the consumer, this warranty is void. LEDGlow Lighting, LLC. shall not be responsible for any consequential damages which arise from the use and/or installation of the product. If the kit is installed in any manner other than specified, LEDGlow Lighting, LLC. reserves the right to deny any warranty claims at the discretion of the technical support department. The one year warranty is not transferable and is valid for up to one year from the original date of purchase. Any product return must include the original packaging, a statement of the alleged defect and an RMA number must be provided. All RMA numbers are valid for 14 days from issued date. Upon receipt of the returned product, the company will test the product for defect. If the results of the testing do not support the warranty claim, do not reveal any defect or indicate consumer negligence in the installation and handling of the product, then the product will be returned to you and you will be charged a reshipping fee. If the product is returned from an address within the continental United States, within the first 14 days after purchase, and is found to be defective, LEDGlow Lighting, LLC. will cover the cost of the return shipping with an emailed return label. This offer is only valid for the continental US. All international shipping, customs fees and/or duty charges are solely the responsibility of the consumer.

Additional Disclaimer Terms

Lights are for off road use only; please check your local and state laws for the proper use of this product.

- Improper installation of electricity-using products such as lighting may cause damage to any vehicle or device to which the improperly handled or installed lighting is attached.
- Improperly installed product may cause electrical injury to persons.
- It is recommended that the kit be installed by a licensed professional.
- LEDGlow Lighting, LLC. assumes no liability for the installation of the product.
- Warranty or liability will not exceed the product purchase price which shall be the buyer's sole and exclusive remedy.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE WARRANTIES DESCRIBED ON THE FACE HEREOF INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. (LEDGlow Lighting, LLC. AT IT'S DISCRETION, MAY PROVIDE REMEDY OF RETURN OF PURCHASE PRICE OR REPAIR OR REPLACEMENT OF DEFECTIVE PRODUCT AS BUYERS SOLE AND EXCLUSIVE REMEDY.)

LEDGlow Lighting, LLC.
150 Cooper Road - Suite A-2 West Berlin, NJ 08091